

INSTRUKCJA UŻYTKOWANIA

1. Prosimy o zachowanie niniejszej instrukcji do przyszłego użytku.
2. Prosimy nie modyfikować produktu ani elementów montażowych w jakikolwiek sposób. Modyfikacje mogą wpłynąć na integralność konstrukcji, a części zamienne w takim przypadku będą kosztem kupującego. Nieodpowiednie użycie lub niewłaściwe zastosowanie produktu jest wyraźnie zabronione i zwalnia producenta z wszelkiej odpowiedzialności. Produkt musi zostać zamontowany przez osobę dorosłą przed użyciem.
3. Produkt może być używany wyłącznie pod stałym nadzorem osoby dorosłej. Produkt nie jest odpowiedni dla dzieci poniżej 36 miesięcy, ze względu na brak dodatkowych zabezpieczeń oraz ograniczone możliwości poznawcze małych dzieci.
4. Produkt spełnia wszystkie wymagania bezpieczeństwa europejskich norm EN 71-1, EN 71-2, EN 71-3 oraz EN 71-8. Przeznaczony wyłącznie do użytku domowego – wewnątrz i na zewnątrz.
5. Zastosowanie produktu jako elementu ramy zabawowej lub jakiegokolwiek innej konstrukcji musi zapewniać brak ryzyka zakleszczenia.
6. Podczas montażu produktu należy zwrócić uwagę na minimalny wymagany odstęp od przeszkód, takich jak ściany, ogrodzenia itp. Odległość ta musi wynosić co najmniej 2 m. Nie może dochodzić do nakładania się stref wolnych lub stref bezpieczeństwa.
7. W tej strefie bezpieczeństwa nie powinny występować żadne twarde, ostre ani kanciaste przedmioty. Powierzchnia pod produktem nie może być wykonana z asfaltu, betonu ani innego twardego podłoża. Zalecamy demontaż i przechowywanie wszystkich akcesoriów w okresie zimowym, ponieważ właściwości zamrożonej ziemi nie są odpowiednie do bezpiecznej zabawy.
8. Wszystkie elementy produktu należy regularnie sprawdzać. W sprawie części zamiennych lub rozbudowy wyposażenia placu zabaw prosimy kontaktować się z dostawcą. Zapewni to utrzymanie bezpieczeństwa.
9. Produkt należy instalować w bezpiecznej odległości od sąsiadujących elementów zabawowych, takich jak huśtawki, zjeżdżalnie czy karuzele. Nie należy instalować produktu w miejscach, które pozwalałyby dzieciom dotrzeć do sąsiednich konstrukcji.
10. Instrukcja montażu znajduje się na ostatniej stronie. Zamontować produkt przy użyciu dołączonej śruby i podkładki. Upewnić się, że koło może nadal się obracać. Następnie zatrzaskać osłonę na środku koła.

KONSERWACJA I KONTROLA

Częstotliwość kontroli i konserwacji zależy od rodzaju urządzenia, użytych materiałów oraz innych czynników (np. intensywnego użytkowania, aktów wandalizmu, lokalizacji nadmorskiej, zanieczyszczenia powietrza, wieku urządzenia itp.).

Jeśli kontrole nie są wykonywane, urządzenie może przewrócić się lub stać się niebezpieczne.

Szczególnie ważne jest, aby stosować się do zaleceń dotyczących konserwacji na początku każdego sezonu oraz w regularnych odstępach podczas sezonu użytkowania.

Regulaminowa kontrola wzrokowa (co tydzień do co miesiąc):

- Sprawdzić, czy wszystkie śruby i nakrętki są dobrze dokręcone.
- Sprawdzić powierzchnię amortyzującą pod kątem obcych przedmiotów.
- Sprawdzić, czy nie brakuje żadnych elementów.
- Sprawdzić odległość urządzenia od podłoża.

Kontrola operacyjna (co 1-3 miesiące):

- Sprawdzić stabilność konstrukcji.
- Sprawdzić każdą część pod kątem nadmiernego zużycia i wymienić uszkodzone elementy zgodnie z instrukcją producenta.

Kontrola roczna (1-2 razy w roku):

- Sprawdzić obecność rdzy i korozji.
- Sprawdzić każdą część pod kątem zużycia i wymienić uszkodzone elementy zgodnie z instrukcją producenta.

OSTRZEŻENIA!

- Nieodpowiednie dla dzieci poniżej 36 miesięcy.
- Wyłącznie do użytku domowego, wewnątrz i na zewnątrz.
- Używać wyłącznie pod bezpośrednim nadzorem osoby dorosłej.
- Ryzyko zadławienia – małe części.
- Ryzyko uduszenia.

Manuals online –
scan the QR code



PL, EN DE, CZ, SK, SL,
LT, LV, EE, HU, RO, HR,
RS, FR, IT, ES



INSTRUCTIONS FOR USE

1. Please keep this instruction sheet safely for future reference.
2. Please do not modify the product or the assembly details in any way. Modifications will affect the structural integrity and replacement parts will be at the buyer's expense. Inappropriate use or faulty application of the product are explicitly forbidden and absolve the manufacturer of all liability. This product needs to be mounted by an adult before use.
3. The use of the item is allowed only under continuous supervision by an adult. The product is not suitable for children under 36 months, due to a lack of extra safety precautions and taking into account the limited mental capacities of toddlers.
4. This product meets all security aspects of the European standard EN71-1, EN71-2, EN71-3 and EN 71-8. It is only suitable for domestic use, both indoors and outdoors.
5. The application of the item as part of a play frame or any other construction will have to be such that it excludes all risks of entrapment.
6. When mounting or assembling the product attention should be given to the minimum required distance between the product and eventual obstacles: walls, fencing,... The distance should be a minimum of 2 m. There cannot be an overlapping of surrounding free spaces or safety areas.
7. In this safety area no hard, angular or pointed objects should be present. The surface underneath the product should be flat and shockabsorbing. The product must not be placed on asphalt, concrete or any other hard surface. We advise the removal and storage of all accessories during the winter because the characteristics of the soil (when frozen) are not suitable for safe play.
8. All pieces should be checked regularly. For replacement material and expansion of the playground equipment, please contact the supplier. Consequently safety will be guaranteed.
9. This product should be installed at a safe clearance from adjacent swing elements, slides, carousel etc. This product should not be installed in locations where it would allow or encourage children to reach adjacent structures.
10. See the last page for assembly instructions. Mount the product using the screw and washer included. Pay attention that wheel can still rotate. Click the cover plate over the center of the wheel.

INSPECTION AND MAINTENANCE

The frequency of inspection and maintenance will vary with the type of equipment or materials used or other factors (e.g. heavy use, levels of vandalism, coastal location, air pollution, age of equipment, ...). If these checks are not carried out the activity toy could overturn or otherwise become a hazard. It is of particular importance that the maintenance instructions be followed at the beginning of each season as well as at regular intervals during the usage season.

Routine visual inspection (weekly to monthly):

- Always check that the bolts and nuts are securely fastened.
- Check the shock absorbing surface for objects that don't belong there.
- Check for missing parts.
- Check the equipment ground clearances.

Operational inspection (1 to 3 months):

- Check the stability of the construction.
- Check every part for excessive wear and replace defective parts in accordance with manufacturer's instruction.

Annual inspection (1 to 2 times per year):

- Check for rust and corrosion.
- Check every part for excessive wear and replace defective parts in accordance with manufacturer's instruction.

WARNINGS!

- Not suitable for children under 36 months.
- No specific precautions for toddlers.
- Only for domestic use. For indoor and outdoor use.
- To be used under the direct supervision of an adult.
- Choking hazard. Suffocation hazard. Small parts.

